

ALIMENTATION 230 V 50Hz STROMZUFUHR 230 V 50Hz MAIN SUPPLY 230 V 50Hz	L N ⊕	ALI	1 2 3
THERMOSTAT D'AMBIANCE RAUMTHERMOSTAT ROOM THERMOSTAT	→ ↓ N	TAM	4 5 6
ACCELERATEUR HEIZUNGSPUMPE HEATING PUMP	L N ⊕ 		7 8 9
POMPE DE CHARGE SPEICHER LADEPUMPE LOADING PUMP	L N ⊕ ⊕		10 11 12
VANNE 3 VOIES 3 - WEGE MISCHER 3 - WAY VALVE	⊕ ⊕ N ⊕		13 14 15 16
VANNE DE SECURITE SICHERHEITSVENTIL SAFETY VALVE	L N	VS	17 18
CONTACT DE SECURITE SICHERHEITSKONTAKT SAFETY CONTACT		CS	19 20
LOGIQUE DE POMPE PUMPENLOGIK PUMP LOGIK		LP	21 22
THERMOSTAT ANTIREFOULEUR ABGASÜBERWACHUNGSTHERMOSTAT DRAUGHT DIVERTER THERMOSTAT		TAF	23 24
EXTERIEURE AUSSEN EXTERNAL		SEXT	25 26
CHAUDIERE KESSEL BOILER	⊕	SCH	27 28
BALLON W W E SEPARATE CALORIFIER	⊕	SB	29 30
DEPART VORLAUF WATER FLOW	⊕	SDEP	31 32
AMBIANCE RAUM ROOM	B A D C	COMMANDE A DISTANCE	33 34 35 36

SONDES - FUHLER - SENSOR

T40 (SM) CE



